# PREPROGRAMMED TELEVISION REMOTE CONTROL



URC-4110

**INSTRUCTION MANUAL** 

#### Installing the Batteries

Your TOTAL CONTROL needs two new AAA/LR03 alkaline batteries.

- I Push down on the tab and lift the cover off.
- 2 Match the batteries to the + and marks.
- 3 Press the battery cover back into place.

#### Features and Functions

Red Light (LED) The LED flashes red to show that the remote is working.



The Power (or Standby) key operates the same as on your original remote.



The SET UP key is used to set up your TOTAL CONTROL and to access special functions.



The Volume keys adjust the volume just as your original remote.



The Programme keys operate the same as on your original remote. If your original remote does not have channel or programme up/down keys, the TOTAL CONTROL may not operate these functions either.



The Mute key operates the same as on your original remote.

### **Entering Your Code**

The TOTAL CONTROL is preprogrammed with codes for the most popular remote-controlled TVs.

Starting on page I you will find the Set-Up Code section. This section lists the codes for your TV by brand name. For each brand name, the most popular codes are listed first.

To enter a code for your TV, use the Programme and Volume keys on the TOTAL CONTROL as follows:

$$Volume + (up) = I$$



Volume - 
$$(down) = 2$$



Programme + 
$$(up)$$
 = 3





For example, to enter the code for a Thomson TV (code 2l244), press Volume - (=2), Volume + (=1), Volume - (=2), Programme - (=4).

The following pages give you step-by-step instructions for setting up your TOTAL CONTROL for use with your TV.

## Setting Up Your TV

To set up the TOTAL CONTROL for your TV:

- Find your TV code in the Set-Up Code section (starting on page I). Codes are listed by brand name. The most popular code is listed first. Turn on your TV.
- Press and hold down the SET UP key until the red light blinks twice.



3 Enter your **five-digit TV code** according to the chart on page 3. The red light will blink twice.



4 Aim the TOTAL CONTROL at your TV and press **Power**. Your TV should turn off.



For easy reference, write your TV code in the five boxes.



To turn on your TV, press the Power or Programme + key depending on your TV.

Note: If your TV does not respond, try all the codes for your brand. If the codes do not work, try the search method (page 5), even if your brand isn't listed at all.

## Searching for Your Code

If your TV still does not respond to the TOTAL CONTROL after having tried all the codes for your brand, try searching for your TV code.

- Turn on your TV.
- Press and hold down the SET UP key until the red light blinks twice.



3 Press Programme - three times. The red light will blink twice.



Alternate between Programme- and Power until your TV turns off. You may have to press these keys many times, so please be patient.





When your TV turns off, press the **SET UP** key to store the code. The red light will blink twice. Your TOTAL CONTROL is ready to run your TV.



### Getting codes from the TOTAL CONTROL

It's easy to get the five-digit code for your TV after your device is set up. To get your TV code:

Press and hold down the SET UP key until the red light blinks twice.



Press Programme -, Programme -, then Programme +.



For the first digit of your 5-digit code, press **Volume+** and count all the red blinks.



4 For the second digit, press Volume- and count all the red blinks



For the third digit, press Programme+ and count all the red blinks.



6 For the fourth digit, press **Programme-** and count all the red blinks.



For the fifth digit, press the Mute key and count all the red blinks. Now you have your five-digit code.



Note: Write down the five-digit code for your TV on page 4.

#### Helpful Hints

Problem:	Solution:
The red light does not blink when you press a key?	Replace batteries with 2 fresh, new AAA/LR03 alkaline batteries.
The TOTAL CONTROL does not respond after pressing a key?	Make sure you are using new batteries and are aiming the TOTAL CONTROL at your device.
The TOTAL CONTROL does not operate your TV?	A) Try all the codes listed for your brand. B) Try the search method on page 5.
Your brand is not listed in the TOTAL CONTROL code section?	Try the search method on page 5.
The TOTAL CONTROL is not performing commands properly?	You may be using the wrong code. Start the search method over again.
Your TV switches to programme I when you press the Power key before switching off OR you must press Power twice to switch on your TV?	Press and hold down the SET- UP key until the red light blinks twice.Then press: (Programme -) (Programme +) (Programme -).

If you have any questions about the operation of your new TOTAL CONTROL Universal Remote Control, you may call our consumer help-line for assistance. Before calling, please read this manual carefully to find an answer to your question. If you cannot find a solution in this manual, please complete the information below.

Your TOTAL CONTROL remote model: URC 4110

Date of purchase: / / Day / Month / Year

In Australia: 1800 812 261

opening hours: 8.00am - 5.00pm (Mon-Fri.)

(The first row is an example of how to complete this table)

TypeBrandModel No.Remote Model No.TVSabaVKM 7251RC 24035

## Codes TV

TV		ASA	13111 22412 12242 12444 12343
Abex	11424	Asberg Asora	12314 12442 32114 11311
Accent	32114	Asuka	14412 21244 14344 21412
Acec	11314		14411
Admiral	12343 12421 23432 14341	Atlantic	14344 14322 21233 22224
7 tarrii a	21244 13433		32114
Adyson	14411 14344 11424	Atori	11311
Agashi	14344 21244	Auchan	13433 23324
AGB	31234	Audiosonic	13121 14411 23132 22331
Agef	12343		21244 14412 24114 32114
Aiko	23133 11433 24131 12244	Audioton	14411 23132 21244 24114
	23111 21244 14411 32114		
	11311 14344	Ausind	12314
Aim	21332 32114	Autovox	12343 14322 21121 12314
Akai	23111 14324 23133 24131		14411 21143
	11433 11311 12244 14412	AWA	11313 11434 11311 13421
	13433 31234 32412 32114		23142 23414 14344 32422
	32241 24424 14411 33143		32114
	14344 21244 24224 14132	Ayomi	21122
	23211 32422	AYR	31343
Akiba	14412 21412 24243 21442	Baird	13121 14231 22343 14222
	32114		14224 12244 12311 14411
Akito	32114		14324
Akura	14412 21412 21334 11311	Bang &	
	22442 23414 14113 21244	Olufsen	32141 12343 21333
	33414	Barco	23214 13433
32114		Basic Line	14412 11311 23142 13433
Alaron	14344		21412 14411 24243 32114
Alba	14412 21113 11311 23432	Bastide	14411
	23132 22433 23133 14344	Baur	13332 22123 31343 14233
	21143 13433 32241 24443	ъ .	23111 31211 32114
	11434 33414 32233 32114	Bazin	14411
Alcyon	12314	Beaumark	14132
Allorgan	14322 21442 14411	Beko Beon	23132 32422 32114
Allstar	32114		23432 11424 32114 22331 23132 23441
Ambassador		Best Bestar	23132 23142 32114
Amplivision	14411 23324 22224 23132	Binatone	14411
A manaduse of	14101 11011 01004 01044	Black Star	21143
Amstrad	14131 11311 31234 21244 14412 23133 24131 14113	Blacktron	21412
	23112 23414 33244 32241	Blackway	21412
	32114	Blaupunkt	31343 14233 14244 14341
Anam	11311 32114	Diaupunkt	22243 24224 24243
Anam	11011 02114	Blue Sky	14412 21412 24243 24443
National	21212 32114	Dido oity	33414 32114
Anglo	11311 21244	Blue Star	21412
Anitech	11311 12314 21244 21412	Bondstec	21143
Ailteon	32114	Boots	14411
Ansonic	23132 21434 12442 11311	BPL	21412 32114
7 11 10 01 110	23142 13433 23413 21233	Brandt	13121 23323 21121 22321
	21143 11314 24114 12444		14234 14242 21423 22323
	32114		32144 33131 24343
Apollo	24411	Brandt	
Arc en Ciel	23323 13121 14234 32144	Electronique	e21423 22323 32144
0 0 0.01	22321 14242	Brinkmann	23432 33414 32114
Arcam	14344 23323 14411	Brionvega	12343 23112 32114
Aristona	32114 11314	Britannia	14344 14411
	s 22424  32114	Brother	21244
	13433 23324 21121	Bruns	12343 22111 24114

BSR	13433 21442	Daytron	11311 23142 32114
BTC	14412	de Graaf	14324 12114 13433
Bush	33414 14412 21113 13433 11311 11434 21412 22433	Decca Deitron	12244 31234 14411 32114 14412 32114
	23133 23142 21244 23111	Denko	21244
	24443 14324 32241 21442	Denver	32114
	14411 32114	Denon	13331
Canton	14412	DER	14231 14222
Capsonic	21244	Desmet	22224 11311 32114
Carad	32432 32114	Diamant	32114
Carena	24243 32114	Digiline	32114
Carrefour Carver	11434 12242 12211 32114 14112	Dixi	11311 22111 21143 14411 32114
Cascade	11311 32114	Domland	23312
Casio	32114	DTS	11311
Cathay	32114	Dual	14411 12211 22343 21233
CCE	14411 32114		22424 23312 23323 22123
Centurion	32114		13433
Century	12343 14341 21143 21122	32114	10010 10111 10110 11011
CGE	12312 12314 21143 13433	Dumont	12343 12444 12442 14341 14411 12242 12244
CGE	21334 23432 23132	Dynatron	32114
Cimline	11311 21113 14412	E-Elite	14412
City	11311	Edison-	2
Clarivox	23432 12242 12442 32114	Minerva	24443
Clatronic	14412 21244 23132 23133	Elbe	24133 21122 21233 23112
	14411 12314 21143 11311		21434 23132 13433 14412
01 1	12442 22224 32233 32114	EII 01	23413 32432 31234 32114
Clayton CMS highted	23231	Elbe-Sharp Elcit	31234 12343 21143 31234 12442
Concorde	11311	EICIL	13433
Condor	14344 21143 21412 22224	Elekta	21244 21412
	23132 11311 12442 23413	ELG	32114
	23432 13433 32114	Elin	14344 13111 12444 23111
Conic	11424		24224 13433 11311 32114
Contec	14344 11311 13421 11313	Elite	14412 22224 32114
Continental	11434	Elman Elta	12442 11311 21244 14344
Edison	13121 21121 14234 14242	Emco	21143
Luison	23323 22321 21423 24443	Emerson	14131 14341 12343 21143
	32144	2	23133 12242 21412 22224
Cosmel	11311 22331 32114		23111 32114 14132
Crezar	14341	Emperor	21412
Crosley	12343 21143 12312 12314	Erres	11314 32114
Cuarra	13433 14341 11311 23132 12314 23441	ESC Etron	32114 11311 13433 32114
Crown	32233 23432 14324 24443	Eurofeel	21244
	12141 22333 32422 32114	Euroman	14344 21244 14411 23441
CS	12111 22000 02 122 02111	2010111011	23132 32114
Electronics	21143 14344 14412	Europa	32114
CTC	21143	Europhon	31234 12442 14341 14411
Curtis			21143 13433 14344 32114
Mathes	12421 13331	Expert	14322 23324 21233 13433
Cybertron Daas	14412 22111	Exquisit	21143 32114
Daas	11311 14344 23142 14412	Fenner	23142 11311
Buowoo	14411 33124 32114	Ferguson	12311 21423 14224 14222
Dainichi	14412 14344	3	22323 21122 14231 13121
Dansai	21244 11424 11433 14344		32124 33131 12444 22343
_	11311 11434 14411 32114		11433 32114
Dansette	23414	Fidelity	14231 14344 23133 13433
Dantax Datsura	23132 14324	Filsai	21244 23111 23414 32114 14411
Daisura Dawa	32114	ı ııəal	17711
Dawa	OL 117		

Finlandia	14324 22412 23111	GoldStar	23132 21432 11424
	13433 12244		11311 23211 14411
Finlux	13111 12444 22412		21143 14344 13433
	14411 12244 13433		14132 23111 12114
	12314 31234 12242		13121 32422 32114
	12343 12442 23413	Gooding	24443
	33143 31114 24424	Goodmans	11434 12244 11311
	14341 32114		21244 31234 21432
Firstline	21442 22231 14344		23142 24443 23114
THOUNIO	23142 23231 21143		23133 32114 22343
	11311 13433 12442		21113 11433 24424
	14411 23413 21122		32124 11424 14411
	12244 21113 33414		33124 22323 33414
	14324 33124 32114		14412
Fisher	12444 14411 11434	Gorenje	23132 23441
	12211 14324 23132	GPM	14412
	32113 22111 12121	Gradiente	12141 14112
	12343 13421 23111	Graetz	23111 23133 13433
	13433 22123 12244	Gran Prix	33244
Flint	24243 12244 14412	Granada	23324 14432 11314
I IIIIL	21244 32432 32114	Granaua	12121 12244 13332
ENID			
FNR	12442		13114 14324 14411
Forgestone	14231		12314 11434 22333
Formenti	12343 14341 14344		31234 24411 22323
	22224 13433 12314		32124 13433 32114
	32114	Grandin	21412 14412 23324
Formenti-			11311 22224 13433
Phoenix	14344 22224		24243 32233 32432
Fortress	12421 12343		23142 32114
Fraba	23132 32114	Gronic	12442 14411
Friac	11311 12442 23441	Grundig	31343 14233 24443
	23132 32114		12242 12314 21121
Frontech	21143 21244 24224		32114 32313 11311
	14411 11311 13433		11434
Fujitsu	14322 12244 12442	Halifax	21244 14344 14411
	14411 13433 11311	Hampton	14344 14411
	22424	Hanimex	21442
Fujitsu		Hanseatic	21434 21412 13433
General	11311 14411 14322	- iaiiooaiio	23111 23312 14341
Funai	21244 21442 22123		22224 12211 24114
Galaxi	12442 32114		23132 11311 21442
Galaxis	23132 23432 12442		14411 21334 12343
Galaxis			
	32114		23211 32114
GBC	14341 13433 11311	Hantarex	11311 14341 21444
	23142 14412		12442 31234 32114
GE	22343 14132 21412	Hantor	32114
	32124 21423 13121	Harwood	11311 23414 11424
	22323		32114
Geant		Hauppauge	32114
Casino	13433 23324	HCM	21244 11311 21412
GEC	12113 12244 13433	I HOW	23414 14411 14412
GEC			
	23111 31234 14411	1	23432 32114
	32114	Hema	14411 11311
Geloso	14341 21143 11311	Hifivox	13121 14234 14242
	13433 23142		23323 32144
General	13121 21423 24343	Highline	21244 32114
General		Hikona	14412
Technic	11311	Hinari	14324 11434 14412
Genexxa	14412 23414 13433	1 1111611	11311 13433 23114
Genexia	11311 32114		22433 24213 24443
0			
Germanyox	14341	1	21113 21442 32114
Goldfunk	33414	Hisawa	21412 14412 23324
Goldhand	14344		24243 32432
Goldline	22331	Hit	12343
Goldline	22331	Hit	12343

Hitachi	14431 11434 12114 12113		14322 13433 23111 21233
	24411 13433 22343 14234		12444
	14242 14411 11424 21334		23441 23132 21412 12442
	31234 12244 13331 13111		32432 21244 32114
	14132 32114 13121 14341		32114
	31114		14344
Hitachi		KB	
Fujian	13114		13433
Hitsu	11311 24243 14412		23112 21113 21143 12442
HMV	12343		24114 23132 23413 32432
	11314 32114		23211 32114
Hoshai	14412 24243	Kennedy 1	14322 14341 13433 24133
Huanyu	23142 14344		
Hygashi	14411 14344		14344
Hyper	11311 14344 14411 21143		12442 32114
			14412 23133 32114
Hypersonic	23111		24443
Hypson	21244 14411 21412 24243		32114
	23324 21122 32114	Korting 1	12343 23441 23132 22224
Iberia	32114		
ICE	21244 14411 23133 14412		32114
	14344 11311 32114		23414 21244
Ices	14412 14344		11311
Imperial	21143 23132 23432 13433		21122
	12312 12314 14234 32114		11314
Indesit	21121 14341		14411
Indiana	32114	Kuba	20400
Ingelen	24443 32432 13433		22123
Ingersoll	11311	Kyoshu 2	21244 23414 11424 23432
Inno Hit	11311 12244 14412 21432		20001 11101 10100
	14411 12314 31234 21143		23231 11424 13433
lata va ativa	12442 32114		32114
Interactive	23413		23413
Interbuy	11311 21244 21143 32114		11311 12444 13433 32114
Interfunk	11314 12343 21333 22243		11311
	13433 23111 23132 13121 32144 21143 32114		21143 21244 12244 21442 32233
Internal	33124 32114		32114
Intervision	21412 14411 24243 23133		23132 21432 11424 11311
IIILEIVISIOII	23211 24224 23132 23312		23211 14411 21143 14344
	24443 14412 12442 13433		13433 14132 23111 32422
	21244 21143 11311 32114		13121 32114
Irradio	11311 14412 21143 21432	Liesenk &	10121 02114
iiiadio	12314 23133 32114		22243 32114
Isukai	14412 21412 24243 32114		22243 11314 32114
ITC	14411		11311 21244 23142 14412
ITS	23133 14412 21412 21244		33414 32114
	14344 32114		11311
ITT	13433 24424 23111 24411		11424
	14231 22412 22333 14324		12343 21434 23132 32114
	32432		11313 14231 23133
ITT Nokia	23111 13433 24411 24424		33414
	22412 14324 22333 32422		14322 23112 13433 21233
	32432 33143		23413 23142 11311 32114
ITV	21244 21143 23142 32114		14322 23112 13433 21233
Jean	11434	2	23111 14411 21244 12311
JEC	11433		32114
JMB	24213	Lux May	11311 32114
JVC	12141 14222 11434 14224		21121 21432 24424 31114
	14231 23133 14412 32422		23111 14324 13433 22412
	23432		24411
Kaisui	14412 21412 14344 24243		14132
	14411 11311 32114	Madison 3	32114
Kamp	14344		
•	'		

Magnadyne	12343 21143 31234 1 13433	12442	Multitech		11311 23132		
Magnafon	31234 14341 12314 1	12442		32114			
	14344 12311		Murphy	12444	14344	12244	13433
Magnavox	32114 11434						
Magnum	33244 32114		Musikland	14412			
Mandor Manesth	21244 21113 14411 21244 2	20004	Myryad NAD	32114 14132	00111		
Manestn	21113 14411 21244 2		Naiko		32114		
Manhattan	33414 32114	02114	Nakimura		32114		
Marantz	32114		NAT		22334		
Marelli	12343		National		14432	21121	
Mark	14411 14344 23142 1	11311	NEC		11434		24243
TTICLI IX					23142		
Masuda	23133 14412 11311 2	21244		32114			
	32114		Neckermann	23132	31211	14244	32114
Matsui	21113 14131 11311 2	22433		13433	22243	23432	12343
	11313 12244 11434 3				21143	14411	23413
	24443 14411 21442 2			22224			
	24131 24213 32233 2		NEI		23133	32114	
	31234 11433 13433 1	14324	Nesco	21143			
	12121 14233 22323		Netsat	32114			
Matsushita	21212		Network	11424		00400	
McMichael	12113		Neufunk		32114		
Mediator	32114 11314		New Tech	24224	32114	22343	14411
Medion Megas	33414 32114 32432		New World	14412			
Megatron	13331 14132		Nicamagic	14344			
	22412 13121 22343 1	12211	Nikkai		14412	14411	21244
Melectronic	21143 13111 12444 2		INIKKAI		11433		
	11311 14411 24424 3				11434		1-10-1-1
	14344 23413 13433 2		Nikko	14132	11404	02114	
	32114		Nobliko		12314	12242	14344
Melvox	23324		Nogamatic		13121		
Memorex	11311 14132 21212		Ü	22321			
Memphis	22331 12244 11311 2	23231	Nokia		13433		
					22333		
Mercury	11311 32114				32422	22412	22224
Metz	12343 14233 31343 2			32432	04.400	00000	4 400 4
	21123 14341 21333 2	23123	Nordmende		21423		
MGA	23234 33414 32114 14132				14242 14233		
Micromaxx	33414 32114		Novak	11314		22323	32114
Midland	11424		Novak		23142	2211/	
Minerva	24443 31343 14233 1	12242	Oceanic		23324		21442
WIII IOI VA	12314 21121 31234		Occurro		24411	20111	21772
Minoka	23414 32114		Odeon	21244	2-1-11		
Mistral			Okano	23132	21244	12244	32114
Electronics	14231		Omega	21244			
Mitsubishi	13114 12343 11434 2	21121	Onwa	23133	14412	24131	32241
	22442 14231 31343 3	32114		12442			
	12421 14132		Opera	32114			
Mivar	21434 21432 21433 2	23132	Optimus	21212			
	12314 14344 31234		Optonica	12421			
Monaco	11311		Orbit	32114			
Morgan's	32114		Orion		21442		
Motion	12314				11313		
Motorola	12421				21444		
MTC	23132 14344		Oulina		21244	23414	31234
MTEC	11424		Orline		32114		
Multi- broadcast	14231		Ormond Orsowe	23231 31234	33414		
Multistandard			Orsowe	31234			
	33414 32114						
IVIUILITEC	00717 02119						

Osaki		14412			Prima		11311	21244	
		21334	23414	23142	Prinz	12244			
		32114			Profex	11311	13433	23111	12314
Osio	32114								
Oso	14412				Profi	11311			
Osume		12244	11434	11424	Profitronic	12442			
		32114			Proline		12244	11314	33131
Otto Versand					ъ .	32114	00400	00440	00000
		14233			Prosonic			23142	32233
		14341					33414		10110
		22123			Protech			21143	
		22343	24114	31234		21244	23432	22331	33414
Pael	11311 14344				32114	21412			
Palladium		31211	14044	22422	Proton	14132			
rallaululli		21143			Provision	32114			
		14341			Pve		1121/	12343	221/12
	10400	14041	14411	20410	Pvmi	11311	11014	12040	20142
Palsonic	21244	23414	14411	23211	Quadra	11011			
i dioonio	32114	20111	1-1-11	20211	Vision	23324			
Panama		14411	21244	14344	Quasar	21143	21212		
i dildilla		32114	212	14044	Quelle			31343	23111
Panasonic		14432	21332	14341	Quono			14411	
		21121						12242	
		13433						14233	
Panavision	23413	32114				14341	21244	21432	33414
Pathe								22412	
Cinema	13433	21122	14344	23324		31211	11311	32114	
	22224	21434	14341		Questa	11434	11424		
Pathe					Radialva	13121	14412	13433	22331
Marconi		13121				32114			
	22321	23323	21121	32144	Radiola		11314		
Pausa	11311				Radiomarelli				32114
Perdio		22224	13433	14344	RadioShack		11424		
	32114				Radiotone			23132	
Perfekt	32114						21244	23414	33244
Pershin	23324					32114			
Phase	11424				Rafena	22111			
Philco		12312			Rank	12242			
		21143	13433	23132	Rank Arena	11434			
DI- 111 1 -		13331			RBM	12242	00404	00404	00000
Philharmonic		44044	10110	10010	RCA		32124	33131	22323
Philips		11314 22343		12343	Destistis	12412 11424	1 1100		
Phoenix		22224		22221	Realistic Recor	32114	14132		
FIIOEIIIX		13433			Rectiligne	32114			
Phonola		11314			Rediffusion	23111	11/2/		
FIIOIIOIA	14344	11314	12040	14231	Redstar	32114	11404		
Pioneer		23132	22343	22111	Reflex	32114	22/1/		
Fiorieer		13433			Revox	23132			
Pionier	23132	10400	21420	02114	Rex			21143	13/133
Plantron		11311	32114		TICA	21233		21140	10400
Playsonic	14411	11011	02114		RFT			21434	23132
Policom		12442	13121	14234			12244		20102
. 55711		14322			Rhapsody	14344			
		21333			R-Line	32114			
Рорру	11311	500			Roadstar		21244	14412	23432
Portland		33124				21412			
Powerpoint	24443				Robotron	12343			
Prandoni-					Rowa	21244			
Prince	21143	31234	23111	14341	Roxy	24224			
	12314				Royal Lux	23441	23132	23414	
Precision	14411				-				

Saba		21423			Silva	14344 32114
		13433			Silver	11434 23111
		23111			Singer	12343 12442 21143 23324
		22323	32144	24343	01	24133 11311 32114
C	32124				Sinudyne	14131 12343 21113 12442
Saccs	21122	32432	21/12			14341 21442 21444 13433 23111 31234 14322 32114
Sagem Saisho		31234		11011		31211
Saisiio		14411			Sky	32114
Salora		13433			Smaragd	24443
Galora		22333			Sogera	22224
Salsa	22323		14024	21777	Solavox	11424 23111 12244 13433
Sambers		31234	12314	12442	Colaron	32114
Sampo	11424				Sonawa	14412
Samsung	32114	32313	11311	14411	Sonitron	14324 23132 22333 14411
Ü	24224	23132	21244	12412	Sonneclair	32114
	14344	21432	11424	12244	Sonoko	11311 21244 21412 14411
	14324	33234	32114	14132		32114
Sandra	14344	14411			Sonolor	14324 13433 23324 31211
Sanela	21122					23111 21412
Sansui		32114			Sontec	23132 21442 11311 32114
Santon	11311				Sony	31211 11313 11434 12442
Sanyo		13421				32114
		23132			Soundesign	14132
		14411			Sound &	
		13332			Vision	12442 14412 23142
0		13114	22111	32114	Soundwave	
Save SBR	32114	44044	4 4004	10110	Ssangyong	11424 11311 11424
Schaub	32114	11314	14231	12113	Stag Standard	14412 11311 14411 22224
Lorenz	20/120	23111			Stariuaru	23142 32114
Schneider		11314	12211	22123	Starlite	11311 13433 21244 32114
Ochineldei		22424			Stenway	21412 14412
		21143			Stern	14322 21233 13433 21244
		13433			Otom	23413
Scotland	13433				Strato	21244 11311 32114
Scott	14132				Stylandia	14411
Sears	13332	14113	14132		Sunkai	21442 22433 22231 24243
SEG	22111	14411	21244	11311		14412 21113 24443 32432
	21143	11434	12442	23112		32114
		14344	33414	24443	Sunstar	23133 11311 32233 32114
		32114			Sunwood	11311 32114
SEI		12442			Superla	31234 14344
		21442		14322	SuperTech	11311 14344 32114 14412
		32114			Supra	23142 11311
Sei-Sinudyne					Susumu	22323 14412 21423
		31234	12343	32114	Sutron	11311
0-1	31211	04000	00440	10100	Swissline	21143
Seleco	23413	21233	23112	13433	Sydney	14344 14411 14113
Sencora	11311				Symphonic Sysline	32114
Sentra		11433	1//12	11211	Sytong	14344
Serino		32432		11011	Tandberg	23123 23413 13121 22331
Sharp		13421		21///2	randberg	14234 23112 23111
Onarp		14231		21772	Tandy	14412 12244 14411 21143
Shintoshi	32114	. 7201	51204		·andy	21334 12421 13433
Shorai	21442				Tashiko	11434 12113 14411 13332
Siarem		12343	12442	14341		14112 11424 14344 13433
	31234				Tatung	12244 31234 14411 11313
Siemens	31343	14244	14233	14341		32114
	22243	13421	11424	13332	Teac	14411 24243 21244 14132
	32114					11311 14113 23414 33414
Siera		11314				32114
Siesta	23132					

TEC	14411 21334 11311 21143	Trident 31234 14411
	24343 22323 22331 21233	Tristar 14412 14231
Techica	14412	Triumph 14131 31234 22412 32114
Tech Line	33414 32114	21133
Technema	22224	TVTEXT 95 32114
Technics	21212	Uher 12314 12211 14322 22224
TechniSat	22111	22123 23142 23432 23132
Tedelex Teiron	14411 32422 11311	21233 32114 Ultra 14224
Teleavia	13121 21423 14234 23323	Ultravox 12343 12442 23142 21143
releavia	22321 32144 22343	14344 13433 14341 32114
Telecor	13433 14412 14411 21233	Unic Line 24411 24243 32114
relecoi	23312 32114	United 32114
Telefunken	13121 31132 24343 23323	Universum 22412 13111 31343 14233
rololalikoli	21423 12312 12441 22323	24411 23111 21143 31114
	21242 12311 22343 14234	24424 23132 14244 23432
	32144 33131 14341 32114	11313 13332 21442 11434
Telefusion	32114	13421 11424 12242 13433
Telegazi	13433 21233 14412 21244	21244 12444 23441 23413
Ü	32114	21432 12312 14341 22243
Telemeister	22224 32114	31211 12314 14411 13121
Telesonic	32114	23112 22331 14131 33143
Telestar	32233 32114	33414 11311 32114
Teletech	11311 21143 22331 33414	Univox 22331 12343 13433 21122
	32114	21444 32114
Teleton	14411 21333 14322 13433	Vestel 13433 14411 32114 33414
	21233 11434	Vexa 11311 32114
Televideon	22224 13433 14344	Victor 12141
Televiso	23324	Videologique 14344 14412 14411
Temco	21442	VideoSystem 32114
Tempest	11311 32114	Videotechnic 14344 22224 14411 23142
Tensai	12444 14412 14411 21442	Videoton 13433
	22224 11311 13111 23142	Vidikron 12442 Vidtech 11434 14132
Tenson	23133 23211 21143 32114 22224 11311	Vidtech 11434 14132 Viper 22331
Tevion	33244 33414 32114	Visiola 14344
Texet	14411 23142 11311 14344	Vision 22224 14411 32114
TOXOL	14412	Vistar 21334 14322 23111
Thomson	21423 23323 13121 22321	Vortec 32114
	24343 22323 14234 14242	Voxson 12343 12314 23432 13433
	21121 22343 32144 32124	32114
	33131 32114	Waltham 14411 21334 23432 21423
Thorn	14231 12311 14222 21122	23231 13121 32114
	14224 12312 12444 22323	Watson 22224 13433 14412 14341
	23142 11433 13114 13121	32233 23312 11311 33414
	14431 22343 23111 31211	32114
	31343 12244 32114	Watt Radio 14341 12442 13433 14344
Thorn-		Wega 14341 11434 12343 32114
Ferguson	12444 14222 14224 14231	Wegavox 11311
	22323 11433 13114 13121	Weltblick 22224 14411 32114
TAME	21122 23111 12311	Wharfedale 32114
TMK	14131 14132	White Westing-
Tokai	12244 24224 22331 13433	house 22224 14344 22331 32114 Windstar 21412
Talous	14411 23142 11311 32114 14344 11433 24224	
Tokyo	21412 14412	Xrypton 32114 Yamishi 21412 24243 14412 14411
Tomashi Toshiba	11433 31214 21133 11434	32114
TUSTIIDA	12242 12442 14411 13121	Yokan 32114
Towada	12442 14411 13121	Yoko 14411 14412 21244 11311
Toyoda	11311	23441 23132 22333 14344
Trakton	21244	21143 32114
Trans		Yorx 14412
Continens	14411 32114	Zanussi 14322 14411
Transonic	24243 32313 21244 32114	Zenor 22333
Transtec	14344	

#### Guarantee

TOTAL CONTROL warrants to the original purchaser that this product will be free from defects in materials and workmanship under normal use for a period of one (1) year from the date of the original purchase. Product will be replaced free of charge if it has been proven to be defective within the one (1) year period when said product is returned at customer expense within the warranty period. THIS WARRANTY DOES NOT COVER ANY EXPENSES INCURRED IN THE REMOVAL AND REINSTALLATION OF THIS PRODUCT

This warranty does not cover damage or failures caused by products or services not supplied by TOTAL CONTROL, or which result from accident, misuse, abuse, neglect, mishandling, misapplication, faulty installation, set-up adjustment, improper maintenance, alteration, maladjustment of consumer controls, modifications, commercial use, fire, water, lightning or other acts of God. This warranty does not cover cartons, carrying cases, batteries, broken or marred cabinets, or any other items used in connection with the product.

There are no express warranties except as listed above. TOTAL CONTROL SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSCOUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD SET FORTH ABOVE. Some countries do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from country to country.

To obtain warranty service during the warranty period, please carefully pack the product and send it prepaid and adequately insured to the address below, together with your purchase receipt or other proof of the date of original purchase.

#### In Australia:

Crest Electronics Importers & National Distributors 7 Prosperity Place P.O. Box 184 Geebung - Brisbane 4034 Queensland

#### IMPORTANT:

IF THE UNIT IS RETURNED WITHIN THE WARRANTY PERIOD, YOU MUST INCLUDE YOUR PURCHASE RECEIPT so that we may establish your eligibility for service and can replace your unit without cost. It would be helpful if you included a note detailing the problem. IF THE UNIT IS RETURNED FOR SERVICE OUTSIDE THE WARRANTY PERIOD, please include a cheque to cover the cost of replacement, handling and return postage. (Prices may differ per model.)

NOTHING IN THIS GUARANTEE AFFECTS YOUR STATUTORY RIGHTS.

Copyright 2002 by TOTAL CONTROL. All rights are reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in any retrieval system, or translated to any language or computer language, in any form or by any means, electronic, mechanical, or otherwise, without the prior written permission of TOTAL CONTROL.

702301

**URC-4110** 





Printed on Recycled Paper

1001/0302